













- D** Montageanleitung
- NL** Handleiding voor de montage
- TR** Montaj talimatı
- FR** Instructions de montage
- CZ** Montážní návod
- HU** Összeszerelési útmutató
- GB** Assembly instructions
- PL** Instrukcja montażu
- RU** Инструкция по монтажу
- IT** Istruzioni di montaggio
- RO** Instructiuni de asamblare
- SK** Montážny návod









A	B	C (mm)		D
1	M122-406	838	186	1/1





- 2x e2  
Ø6.3x13 mm
- 4x e4  
Ø5x11 mm
- 2x f35  
Ø10x50 mm
- 2x g2
- 4x g39
- 8x j30  
M4x22 mm
- 2x p75  
Ø6x60 mm


1 






4




2



3



5

**Pflegehinweis!**

Bitte nur mit einem Staubtuch  
(kein Microfasertuch) oder  
einem feuchten Lappen reinigen.  
KEINE scheuernden Putzmittel  
verwenden!

**Wskazówka dotycząca pielęgnacji!**

Proszę czyścić tylko suchą lub lekko  
wilgotną szmatką do kurzu. Nie używać  
żadnych środków szorstkich!

