











- D** Montageanleitung
- NL** Handleiding voor de montage
- TR** Montaj talimatı
- FR** Instructions de montage
- CZ** Montážní návod
- HU** Összeszerelési útmutató
- GB** Assembly instructions
- PL** Instrukcja montażu
- RU** Инструкция по монтажу
- IT** Istruzioni di montaggio
- RO** Instructiuni de asamblare
- SK** Montážny návod



Ø10mm

§1

A	B	C (mm)		D
1	M122-110	382	310	1/1
2	M122-207	838	330	1/1
3	M122-208	838	330	1/1
4	M122-306	804	280	1/1
5	M122-401	805	382	1/1

45 min

4x **d1**
Ø5x17 mm

12x **f1**
Ø8x30 mm








4x **k55**

8x **p6**
Ø4x35 mm


14x **r1**
Ø15x12 mm #16

14x **r42**

8x **s2**
Ø16



4

**Pflegehinweis!**

Bitte nur mit einem Staubtuch
(kein Microfasertuch) oder
einem feuchten Lappen reinigen.
KEINE scheuernden Putzmittel
verwenden!

Wskazówka dotycząca pielęgnacji!

Proszę czyścić tylko suchą lub lekko
wilgotną szmatką do kurzu. Nie używać
żadnych środków szorstkich!