













- D** Montageanleitung
- NL** Handleiding voor de montage
- TR** Montaj talimatı
- FR** Instructions de montage
- CZ** Montážní návod
- HU** Összeszerelési útmutató
- GB** Assembly instructions
- PL** Instrukcja montażu
- RU** Инструкция по монтажу
- IT** Istruzioni di montaggio
- RO** Instructiuni de asamblare
- SK** Montážny návod







A	B	C (mm)		D
1	S182-002	996	180	1/1
2	S182-101	308	477	1/1
3	S182-102	308	477	1/1
4	S182-103	366	140	1/1
5	S182-201	1000	500	1/1
6	S182-202	1000	477	1/1
7	S182-301	967	462	1/1
8	S182-503	910	100	1/1
9	S182-505	400	100	1/1
10	S182-507	400	100	1/1
11	S182-508	400	100	1/1
12	S182-901	979	320	1/1
13	S182-902	408	940	1/1












6

**Pflegehinweis!**

Bitte nur mit einem Staubtuch  
(kein Microfasertuch) oder  
einem feuchten Lappen reinigen.  
KEINE scheuernden Putzmittel  
verwenden!

**Wskazówka dotycząca pielęgnacji!**

Proszę czyścić tylko suchą lub lekko  
wilgotną szmatką do kurzu. Nie używać  
żadnych środków szorstkich!

**10 24 WW 31****10 24 HH 31  
10 24 HG 31**